**OILGEAR** 



# W P E PREFILL & EXHAUST

PREFILL & EXHAUST VALVE

**Innovative Fluid Power** 



**MAKING MACHINES GO AND PROBLEMS GO AWAY®** 

# OILGEAR

# MAKING MACHINES GO AND PROBLEMS GO AWAY®

# THE WORLD DEMANDS OILGEAR

Oilgear has a rich legacy of more than 100 years manufacturing pumps and hydraulic equipment. We pride ourselves on MAKING MACHINES GO AND PROBLEMS GO AWAY®. For decades, Oilgear has developed hydraulic techniques to meet the unique needs for many equipment manufacturers and end users worldwide.



OILGEAR TRAVERSE CITY, MI USA



OILGEAR FREMONT, NE USA



OILGEAR TOWLER UK



OILGEAR SOUTH KOREA



OILGEAR CHINA



OILGEAR SPAIN

# **Global Service Network**

No matter where you are, Oilgear can quickly and efficiently provide service to you.

Oilgear's large pump manufacturing centers are in Traverse City, Michigan and Leeds, England. Further domestic manufacturing capacity and product specialization are provided by our Fremont, Nebraska, pump manufacturing facility. We also have manufacturing and field service centers in Germany, France, Spain, China and Korea.

# **Engineering and Application Expertise**

Oilgear's engineering capabilities are second to none. Our application and field engineers are factory-trained and have spent years, often decades, working in the market segments they service. Every Oilgear engineer brings this personal experience to the meeting table, plus the collective knowledge gained from Oilgear's more than 100 years of servicing the general industry with innovative fluid power solutions.











# **VPE**

# INNOVATIVE FLUID POWER



# **TABLE OF CONTENTS**

VPE Application, Features and Benefits	4
VPE Operation	5
General Technical Data, Size Designation	6
Model Ordering Information	7
Flow Graph	8-9
Mounting Pattern - Valve Sizes	10
Preferred Valve Codes, Valve Symbols	11
Installation Dimensions Versions CB and CP Standard Range Dimension Specifications	13 14
Installation Dimensions Version CT For Valve Size 130, 190, 250, and 300 For Valve Size 350, 400, and 450	
Installation Dimensions Version CC For Valve Size 130, 190, 250, and 300 For Valve Size 350, 400, and 450	
Installation Dimensions Version CL For Valve Size 130, 190, 250, and 300	20
Weight: Standard Version	21
Proximity Switch Wiring	22
Special Designs	23
Vintage Replacement / Conversion Kits	23

#### VPE APPLICATION

#### **PREFILLING**

The valve is used to connect a cylinder to a gravity or low pressure fluid supply (tank) and allow the cylinder to be filled with fluid when the ram is being withdrawn from the cylinder by means other than the hydraulic fluid applied to the ram, and where the speed is greater than that which can be achieved by the system pump flow. After prefilling, the valve automatically closes. This prevents pump flow into the tank, so that cylinder movement continues at a speed relevant to the pumped volume.

#### **EXHAUST**

Open the valve, using the pilot piston after pressure in the cylinder has been decompressed to a level which will prevent shock, to allow large volumes of oil to be quickly returned to the tank without the need to pass through the rest of the system.


#### FEATURES AND BENEFITS


- Seated design for low leakage
- Guided valve design:
  - Allows for use on various fluids, 1 to 800 cst.
  - Increased seating capability, virtually leak free. Good for locking in pressure
- Precision machined seat giving controlled seat width and constant opening pressures through out the life of the valve and consistent operation form one valve to another
- Metal to metal seat for increased dirt tolerance and leak free operation
- Main valve and pilot piston are not connected giving automatic valve closing at the end of prefill mode
- Horizontal or vertical mounting
- In-Tank, straight line or 90° bend mounting options on request
- Optional valve position switch



# **VPE**







#### VPE OPERATION

All Oilgear prefill valves are similar in design, construction and operation. Detail differences in construction are relative to the size of the valves. The valves can be simply described as consisting of three sub-assemblies. The main headed valve with seat and closing spring, the pilot piston assembly and the casing with low pressure connection.

The main headed valve is fitted with a spring to return the valve to its closed position. However, this spring is also designed to keep the pressure drop low in order to enable the valve to open naturally during the prefill cycle, and may prevent flow to other or lower parts of the system from the tank. The operating piston which is used to open the valve during return is not connected to the main poppet, and can only push the valve open. Valve sizes 40 to 300 mm use a strong spring on the pilot piston to drive the piston back to position independent to the main poppet. The large 350 to 450 mm size valves have a two way hydraulically operated pilot actuator as a spring return becomes impractical. These two methods of returning the pilot piston give positive action without influencing the low pressure drop characteristics of the valve. Unlike other valves where the main valve and the pilot piston are connected, the timing of this return operation is not critical as the main poppet can remain naturally open when the pilot piston is retracted.

Some valves can be fitted with a proximity switch to indicate that the valve is closed. The switch is locked in a removable housing which can be turned to provide a small final signal setting. The switch can only be set to operate prior to closing position to ensure a positive signal and is therefore not an absolute true indication of the valve being closed. To suit individual requirements, valves can be mounted in a customers' special housing or press head. The valve consists of: Main Valve Poppet (1), Seat (2), Main Spring (3), Pilot Piston (4) and Case (5).

#### PREFILLING

When the pressure at Port B falls to create a differential across the valve (from port A to port B) which is sufficient to overcome the force of the Main Spring (3), the Main Valve Poppet (1) will open allowing free flow from Port A to Port B.

#### EXHAUSTING

The pressure acting on Port B holds the Main Valve Poppet (1) on the Seat (2), keeping the valve closed. To allow flow in the return direction (from Port B to Port A) the pressure at Port B must first be decompressed to a level which will not cause shocks in the system. Pressure can then be applied to Port X, the Pilot Piston (4) is then forced down, opening the Main Valve Poppet (1), allowing exhaust flow from Port B to Port A.

#### **■ VPE GENERAL TECHNICAL DATA**

Wales Basine		Confess (Ollman) Daving Costed Tons					
Valve Design		Surface (Oilgear) Design, Seated Type					
Mounting Type		Cylinder and Line Mounting					
Mounting Pattern		Oilgear Standard					
Installation Position		Vertical (Poppet Down) or Horizontal					
	Valve with NBR Seals	-20°C to 80°C					
Ambient Temperature Range	Valve with FKM Seals	-30°C to 80°C					
Hydraulic Technical Data	Max. Operating Pressure	350, 500, 700 and 1000 BAR Depending on Size.					
nyuraune reciinicai Data	Flow Direction	Prefill A to B, and Exhaust B to A					
Seal Material / Fluid	NBR	Mineral Oil Based Hydraulic Fuids, HFB HFC Hydraulic Fluids					
Combination	FKM	Mineral Oil Based Hydraulic Fluids, HFD Hydraulic Fluids					
Temperature Range of Fluid	NBR	-20°C to 80°C					
remperature Range of Fluid	FKM	-30°C to 80°C					
NO. 11 6 P. 11	Permitted	1 to 800 CST					
Viscosity of Fluid	Recommended	10 to 200 CST					
Flitration	For Functional Safety	20/18/15 Up to 500 BARS: 20/16/13 Over 500 BARS					
rittation	For Longer Service Life	18/16/13 Up to 500 BARS: 18/13/11 Over 500 BARS					

## **■ VPE SIZE DESIGNATION**

Nominal Size (mm)	Max. Flow Prefilling CB and CP Version (I/min)	Max. Flow Prefilling CT Version (I/min)	Max Flow Exhausting (All Versions Except CC) (I/min)	Max. Tank Pressure (BAR) CB and CL Versions	Max. Tank Pressure (BAR) CP and CN Versions	Pilot Pressure to Open Valve (BAR) (P=Cylinder Pressure)	Ratio Main Valve to Pilot Piston	Volume Port X (cm³)	Volume Port Y (cm³)
40	255	330	600	15	-	P+3,4+Tank	1:1	17	-
50	450	585	1050	15	-	1.7P+3,7+Tank	1,63:1	17	-
65	700	910	1645	15	-	2,1P+3,6+Tank	2:1:1	17	-
90	1400	1820	3200	15	-	5,6P+4,8+Tank	2:1:1	17	-
130	3400	4420	7500	3.5	16	6P+6,2+Tank	5:6:1	97.5	-
190	7500	9750	17600	3.5	16	6P+4+Tank	6:1	226	-
250	11900	15470	30500	3.5	16	7,8P+5+Tank	7:8:1	506	-
300	20000	26000	45000	3.5	16	10,3P+5+Tank	10,3:1	506	-
350	26000	33800	65000	3.5	16	11P+5+Tank	11:1	785	545
400	34000	44200	85000	3.5	16	11P+5+Tank	11:1	1195	687
450	37000	48100	100000	3.5	16	11P+5+Tank	11:1	1860	968

# VPF



#### VPE MODEL ORDERING INFORMATION

VALVE HK М **EXAMPLE BLOCK NUMBER** 8 10 11 15

Not Available

1 = VALVE TYPE **V** Valve 2 = VALVE FORM P Prefill

3 = VALVE TYPE E Prefill and Exhaust P Prefill Only

4 = VARIATION 40 50 65 90 | 130 | 190 | 250 | 300 | 350 | 400 | 450 CB 90° BEND CL LINE СТ TANK \_ \_ \_ CHECK VALVE ONLY HIGH PRESSURE CP \_ 90° CASE HIGH PRESSURE CN IN LINE CASE XX SPECIAL

Standard Available On Request

6 = MOUNTING With 90° Bend Only, 40, 50, 65, В 90, 130, 300, 350, 400, & 450 Sizes Only 190, 250 Sizes With Check Valve Only

7 = WITH PRESSURE 50 90 | 130 | 190 | 250 | 300 | 350 | 400 | 450 40 65 35 350 BARS 42 420 BARS 500 BARS 700 BARS 70 100 1000 BARS 140 | 1400 BARS \_ **SPECIAL** XX Extended Range On Request -Standard Not Available 8 = EXHAUST FLANGE Sizes 40, 50, 65, and 90 -All Variations 130 & Above All Variations Except "CC" Check Valve Only and "CT" Cylinder and Tank Mounting With Check Valve Only

9 = MATING FLANGE M With Mating Flange and Fasteners N Without Mating Flange

10 = PILOT CONNECTION For Use With Prefill and Exhaust "VPE", Sizes 40, 50, 65, 90, 130, 190, 250, 300 For Use with Prefill and Exhaust "VPE", Sizes 350, 400, and 450 For Use with "Prefill Only" VPP

11 = RATIO & SPRING **HK** Assigned by Factory

12 = ADDITIONS Position Transducer Proximity Switch and Position Transducer Proximity Switch Ν None

13 = DIMENSIONS **M** Metric

14 = SEALS **B** Buna NBR EPDM Viton

15 = DESIGN SERIES \* Assigned by Factory

For non-standard requests, please contact technical sales.




#### **■ FLOW GRAPH - PREFILL / EXHAUST**


#### Prefill (Flow A to B) Exhaust (Flow B to A)

Valve mounted horizontally.

The values of flow and pressure are for an oil viscosity of 40 cst at 40°C



Size: 130, 190, 250, 300






#### **■ FLOW GRAPH - PREFILL / EXHAUST**

Prefill (Flow A to B) Exhaust (Flow B to A)

Valve mounted horizontally.

The values of flow and pressure are for an oil viscosity of 40 cst at 40°C








#### MOUNTING PATTERN - VALVE SIZES


#### Standard W. P. Version

For Valve Sizes: 40, 50, 65 and 90

#### Standard W. P. Version

For Valve Sizes: 130, 190, 250, 300, 350, 400 and 450





NOMINAL SIZE (MM)	40	50	65	90	130	190	250	300	350	350	400	450
NOMINAL PRESSURE	700	700	500	500	500	500	500	500	350	500	350	420
Α	125	150	150	250	350	490	610	700	780	790	895	980
В	102	120	154	250	15°	15°	11,25°	11,25°	10°	7.5°	10°	9°
С	50	60	70	125	280	400	510	585	670	700	765	850
D	51	60	77	125	162	240	285	362	430	430	490	550
E	66.6	79.4	101.6	152.4	200	270	345	440	520	520	595	675
F	33.3	39.7	50.8	76.2	20	16	20	38	40	40	50	50
Н	M20	M24	M24	M48	M30	M45	M48	M56	M56	M48	M64	M64
J	35	36	36	75	45	70	75	85	85	75	100	100
K	50.1	64.6	78.7	128.6	12	12	16	16	18	24	18	20
L	-	-	-	-	245	355	460	525	785	650	900	785



## PREFERRED VALVE CODES - PART NUMBERS

SIZE	W.P.	CODE
40	700 BARS	VPECB40B-70AMBHKNMB*
50	700 BARS	VPECB50B-70AMBHKNMB*
65	500 BARS	VPECB65B-50ANBHKNMB*
90	500 BARS	VPECB90B-50ANBHKNMB*
130	500 BARS	VPECB130B-50ANBHKNMB*
190	500 BARS	VPECB190B-50ANBHKNMB*
250	500 BARS	VPECB250B-50ANBHKNMB*
300	500 BARS	VPECB300B-50ANBHKNMB*
350	350 BARS	VPECB350B-35ANBHKNMB*
400	350 BARS	VPECB400B-35ANBHKNMB*
450	350 BARS	VPECB450B-35ANBHKNMB*

#### VALVE SYMBOLS

#### **WITHOUT SWITCH**

**'VPE' VALVE TYPE** 

Sizes 40, 50, 65, 90, 130, 190, 250 and 300


**'VPE' VALVE TYPE** 

Sizes 350, 400 and 450

**'VPP' VALVE TYPE** 


All sizes







#### **WITH SWITCH**





#### **■ INSTALLATION DIMENSIONS - SEE PAGE 13 - 20 FOR DRAWINGS**

#### **Installation Dimensions Versions Standard Range:**


ND	40	50	65	90	130	190	250	300	350	350	400	450
MWP	700	700	500	500	500	500	500	500	350	500	350	420
D1	48.3	60.3	76.2	114.3	350	490	610	700	780	790	895	980
D2	-	-	-	-	280	400	510	585	670	700	765	850
D3	-	-	-	-	243	350	455	520	555	-	635	715
D4	-	-	-	-	162	240	285	362	430	430	490	550
D5	-	-	-	-	194	273	324	407	480	480	540	610
D6	-	-	-	-	181	225	304	381	386	-	437	488
D7	-	-	-	-	268	320	378	490	490	-	550	610
D8	-	-	-	-	340	405	460	580	580	-	640	715
D9	-	-	-	-	295	355	410	525	525	-	585	650
D10	3/8" BSP	3/8" BSP	3/8" BSP	1/2" BSP	1/2" BSP	1/2" BSP	3/4" BSP	3/4" BSP	25	25	25	32
D11	-	-	-	-	22	26	26	30	25	25	32	45
D12	-	-	-	-	185	220	240	260	260	126	285	310
D13	-	-	-	-	33	48	52	60	61	52	70	70
D14	-	-	-	-	-	-	-	-	30	-	30	33
A1	-	-	-	-	15°	15°	11.25°	11.25°	10°	7.5°	10°	9°
A2	-	-	-	-	15°	15°	15°	11.25°	11.25°	-	9°	9°
H1	219	230	259	300	503	658	750	903	1140	1427	1260	1400
H2	125	150	150	250	106	134	195	235	220	*	255	300
Н3	100	120	154	250	48	50	75	95	150	195	175	210
H4	89	100	130	185	22	16	20	38	35	35	40	40
Н5	31	30	25	75	283	375	485	580	560	-	630	690
Н6	48	57	76	100	85	92	127	161	193	193	220	250
H7	43	45	50	50	45	42	52	81	87	87	100	105
Н8	50	60	70	125	188	295	345	470	586	-	659	783
Н9	50	60	77	125	-	-	-	-	-	1108	-	-
H10	18	-	-	65	493	649	750	895	-	-	-	-
H11	-	-	-	-	85	110	130	130	-	-	-	-
H12	-	-	-	-	463	614	705	850	-	-	-	-
L1	-	-	-	-	230	293	375	405	480	-	540	610
L2	-	-	-	-	26	29	32	38	38	-	42	46
L3	-	-	-	-	3	3	4	4	4	-	4	4
N1	-	-	-	-	12	12	16	16	18	24	18	20
N2	-	-	-	-	12	12	12	16	16	-	20	20

<sup>\*</sup> Consult factory for 3D models



#### **■ INSTALLATION DIMENSIONS**

**Installation Dimensions Versions CB and CP Standard Range** For Valve Sizes: 40, 50, 65 and 90






#### **■ INSTALLATION DIMENSIONS**

Installation Dimensions Versions CB and CP Standard Range

For Valve Sizes: 130, 190, 250 and 300






#### **■ INSTALLATION DIMENSIONS**

**Installation Dimensions Versions CB and CP Standard Range** 

For Valve Sizes: 350, 400 and 450







#### **■ INSTALLATION DIMENSIONS**

#### **Installation Dimensions Version CT Standard Range**

For Valve Sizes: 130, 190, 250, and 300









#### **■ INSTALLATION DIMENSIONS**

#### **Installation Dimensions Version CT Standard Range**

For Valve Sizes: 350, 400, and 450








#### **■ INSTALLATION DIMENSIONS**

#### **Installation Dimensions Version CC Standard Range**

For Valve Sizes: 130, 190, 250, and 300






#### **■ INSTALLATION DIMENSIONS**

#### **Installation Dimensions Version CC Standard Range**

For Valve Sizes: 350, 400, and 450







#### **■ INSTALLATION DIMENSIONS**

#### **Installation Dimensions Version CL Standard Range**

For Valve Sizes: 130, 190, 250, and 300





**Installation Dimensions Version CL Standard Range** 

For Valve Sizes: 350, 400, and 450

**Consult Factory** 




## **■** WEIGHT: STANDARD VERSION

SIZE	CONFIGURATION	VALVE WEIGHT (KG)					
40	СВ	9					
50	СВ	16					
65	СВ	33.5					
90	СВ	58					
	СС	23					
130	СТ	90					
130	CL	115					
	CB/CP	125					
	СС	45					
190	СТ	205					
190	CL	225					
	CB/CP	235					
	СС	90					
250	СТ	365					
250	CL	410					
	CB/CP	445					
	СС	294					
300	СТ	770					
300	CL	790					
	CB/CP	825					
	СС	540					
350	СТ	800					
	CL	836					
	CB/CP	880					
	СС	815					
400	СТ	1190					
400	CL	1215					
	CB/CP	1278					
	СС	1164					
450	СТ	1750					
730	CL	1790					
	CB/CP	1885					



#### PROXIMITY SWITCH WIRING


The proximity switch is set to the poppet closed position, it is a NO contact.



# DETAILS OF PROXIMITY SWITCH (OPTIONAL)

#### **WIRING SCHEME**

RATED SUPPLY VOLTAGE 24 TO 240V AC OR 24 TO 210V DC





#### SPECIAL DESIGNS

Please consult factory for any special needs:

- > Specific mechanical arrangement
- > Specific mounting pattern
- > Specific fluid of fluid conditions
- > Additional monitoring need (Position transducer, etc.)
- > Any other needs



Prefill valve for pure water

#### **■ VINTAGE REPLACEMENT / CONVERSION KITS**

Oilgear studies all kinds of replacement and conversion kits of existing prefill valves (Oilgear and vintage brand / models)



# OILGEAR

#### **World Headquarters**

- **231-929-1660**
- ussales@oilgear.com
- Q 1424 International Drive, Traverse City, MI 49686
- ⊕ www.oilgear.com

#### Americas The Oilgear Company Fremont, NE Office

905 South Downing St. Fremont, NE 68025 USA

#### Oilgear Mexicana S.A.

Calle Argentina 3913, Monterrey, 64930, Mexico

#### Oilgear do Brasil

Av. Ricardo Bassoli Cezare 1009, 13050-080 Campinas, Brazil

#### Oilgear Towler UK Europe

37 Burley Road, Leeds, LS3 1JT, United Kingdom

#### enquiries@oilgear.com

Oilgear Towler S.A.S.

5, Allée des Frères Montgolfier, 77183 Croissy-Beaubourg, France oilgearfrance@oilgear.com

#### Oilgear Towler GmbH

Im Gotthelf 8, 65795 Hattersheim, Germany

info@oilgear.de

#### Oilgear Towler S.A.U.

Entidad Zikuñaga, 62, 20120, Hernani, Spain

#### Asia Oilgear South Korea

167-3 Techno 2-ro, Yuseong-gu, Daejeon City, 34025, South Korea

spark@oilgear.com

Oilgear China Co., Ltd.

3rd Floor, Bldg. A, No.3500 Xiupu Road, Shanghai, China

©2023 THE OILGEAR COMPANY **ALL RIGHTS RESERVED** 

